Continuous Indoor Air Sampling

to Understand Variable Concentrations of Trichloroethene in a Complex Industrial Facility

Cannon Silver, PE, Pam Fahey (CDM Smith) Blaine Hartman (Hartman Environmental Geoscience)

April 10, 2018



CDM Smith

Eleventh International Conference on Remediation of Chlorinated and Recalcitrant Compounds

April 8-12, 2018 | Palm Springs, California

Presentation Objective and Outline

- Objective: demonstrate new tool available to monitor vapor intrusion
 - Compare to existing sampling approaches
 - Better understand fluctuating nature of indoor air concentrations
- Outline:
 - Building layout; contaminant sources
 - Basement problems
 - Basement solutions, including:
 - Continuous indoor air sampling
 - Subsequent steps

Building Sources and Sampling Locations



Contaminant Sources

- Trichloroethene (TCE) present under the main floor is likely from:
 - Leakage from former degreasers
 - Historical operations from former plating shop (southwest area)
- Once present in the subsurface, TCE likely migrated through soil to groundwater beneath the building to the basement
 - TCE volatilizes from water present in basement sumps and drains into indoor air in the basement

Traditional Sampling Approaches

Traditional sub-slab and vapor pin installation



- Summa canisters to sample:
 - Sub-slab vapor
 - Indoor air (breathing zone) 8 hours





Problem: Periodic TCE Indoor Air Exceedences in Building A Basement between 2013 - 2016

Round	Location 093-A	Location 093-X	Location 138-A
Round 15 Aug 2013	13 *		2.9
Round 16 Feb 2014	5.9	8.4	1.6
Round 17 Sept 2014 resample October 2, 2014 093-A-R17A August 21, 2014 093-A-R17B August 27, 2014	9.2 * 12.2 * 10.6 * 9.9 *	 	5.5
Round 18 Feb 2015	1.5	8.3	1.6
Round 19 Aug 2015	3.3		0.87 J
Round 20 Feb 2016 resample March 11, 2016	6.4		12 * 2.4
Round 21 Aug 2016	6.0		2.7
Round 22 Feb 2017	1.8		11 *
All reported concentrations in units of μg/m ³	 Exceeds TCE Indoor Air VISL 8.8 μg/m³ where VISL = Vapor Intrusion Screening Level 		

Basement Indoor Air Exceedences Summa Locations near columns 26 093-A and 138-A and 28 Column 24 138-A Column 26 093-X Column 28 093-A

Additional Investigations in Basement


- Surveyed possible preferential pathway floor features in the basement using a Frog-4000™ field gas chromatograph (March 2016)
 - Identified sumps and floor drains as potential sources of TCE vapor from water beneath basement floor



- Installed additional vapor monitoring points in the walls
- Collected standing water from the sumps, storm drains, lift station and from water ponded behind the freight elevator
- Implemented a continuous air monitoring system for two months (February 24 until April 21, 2017)

Continuous Air Sampling Set Up

Gas chromatography / electron capture detector (GC/ECD)





Continuous Air Sampling Set Up

- Gas chromatography / electron capture detector (GC/ECD) used to analyze for TCE using EPA Method TO-14
 - Provided by Dr. Blayne Hartman
 - Analyzed 15 sampling locations, plus calibration gas
 - Instrument reported ~9 readings at each location per day
 - ~10 minutes to analyze each location
 - Reporting limit 2.0 μg/m3

Groundswell Technologies earth monitoring software provided dashboard

to review results daily






Initial Month TCE Results In Breathing Zone

	INITIAL MONTH TCE CONCENTRATIONS			
	Minimum Conc. μg/m³	Maximum Conc. μg/m ³	Average Conc. μg/m ³	
BACK	0.0	13.4 *	6.2	
BZD-22	0.0	16.5 *	7.4	
BZD-24	2.3	17.9 *	7.8	
BZD-26	3.0	23.3 *	10.7 *	
BZD-28	0.0	11.8 *	3.7	
		* Exceeds TCE IA VISL 8.8 μg/m³		

Sampling Duration: February 24 – March 20, 2017

Indoor Air Summa
Locations 093-A and
138-A vs Continuous
Sampling



Initial Month Continuous Sampling Results

- 8-hour Summa canister sampling results were <u>comparable</u> to continuous sampling
- Results demonstrated that 8-hour Summa canister samples may <u>not</u> be effective for collecting <u>representative</u> samples when indoor air concentrations are close to screening level
- Actual TCE concentrations fluctuate continuously over time
 - Poor correlation with barometric pressure observed
 - Results possibly influenced by measurable rain events
- BZD-28 is closely located to Summa location 093-A
 - Average TCE concentration <u>less</u> than screening level of 8.8 μg/m3

Sampling Results Linked to TCE Sources


- Sampling results positively identified floor features with high levels of TCE vapor
 - Sump near BZD-26
 - HRS5 sump (approximately 3 feet deep below floor surface with approximately 2 inches of standing water)
 - TCE vapor concentrations between 400-600 μg/m³ within sump
 - Sumps and floor drains near BZD-24
 - TCE vapor concentrations between 150-300 μg/m³ within sump
 - TCE vapor concentrations between 10-50 μg/m³ within drains

Solution: Covered Floor Features

- After a baseline of data was established, floor features were covered to measure impact to indoor air results
 - Breathing zone locations immediately decreased to concentrations near zero
 - Concentrations gradually began to increase over time



TCE Concentrations with Conduits Covered




TCE Results In Breathing Zone After Covering Floor Features

	TCE CONCENTRATIONS SUMPS COVERED			
	Minimum Conc. μg/m³	Maximum Conc. μg/m³	Average Conc. μg/m ³	
BACK	0.0	14.4 *	3.4	
BZD-22	0.0	7.8	2.1	
BZD-24	0.0	7.9	3.6	
BZD-26	0.0	14.2 *	4.5	
BZD-28	0.0	10.5 *	2.5	
		* Exceeds TCE IA VISL 8.8 μg/m³		

Sampling Duration: March 20 – April 13, 2017

Covers Removed

- All covers were removed April 13th
- Once covers were removed, TCE concentrations rebounded to previous levels



TCE Results In Breathing Zone After Uncovering Conduits

	TCE CONCENTRATIONS SUMPS UNCOVERED			
	Minimum Conc. μg/m³	Maximum Conc. μg/m³	Average Conc. µg/m ³	
BACK	2.8	16.6 *	8.0	
BZD-22	4.2	19.6 *	9.7 *	
BZD-24	4.4	19.8 *	10.3 *	
BZD-26	5.4	21.7 *	11.1 *	
BZD-28	2.3	19.8 *	7.5	
		* Exceeds TCE IA VISL 8.8 μg/m³		

Sampling Duration: April 13 – April 18, 2017

Subsequent Steps

- Short-term steps accomplished:
 - Sealed duct work to the main floor
 - Added permanent covers over sumps
 - Connected existing sub-slab vapor treatment system to extract vapors from sump
- Long-term:
 - Evaluating source remediation
 - Removing water from sumps
 - Future soil remediation.



Summary of Tools Used

- Vapor Intrusion Monitoring
 - Summa canisters
 - Vapor pins and sub-slab samples
 - Indoor air breathing zone
 - Frog-4000™ gas chromatograph survey
 - Continuous gas chromatography / electron capture detector (GC/ECD)
- Vapor Mitigation
 - Installed indoor air purification units
 - Sealed conduits where vapors may enter
 - Connected sumps to sub-slab depressurization systems

Conclusions

- When indoor air concentrations are close to a health-based screening level, an 8-hour or 24-hour Summa sample may not be representative enough to provide a complete understanding of building compliance
- Continuous sampling over the course of 2 months provided an understanding of the <u>fluctuations</u> and ranges of breathing zone indoor air concentrations as well as VOC concentrations within subfloor sources
- 8-hour Summa canister sampling results were <u>comparable</u> to continuous sampling, but not necessarily <u>representative</u>, given the variable conditions
- Frog-4000™ gas chromatograph survey helpful in identifying sources, but not comparable to either 8-hour Summa or continuous sampling



Questions?

Cannon Silver, PE silvercf@cdmsmith.com